







These signals also available on




GND  
12V

GND








These signals also available on 10-way connector on bottom of PCB.




Extra Butler Heater Regulator (option):  
Fit R101A Omit R101 Fit IC1X






Analogue 'S' Meter (option)  
Select Polarity (Fit One Only)  
Adjust FSD






Remote Console LEDs (option)  
'S' Meter Programmer (option)




See Recommended Modification (Ver. A Pcb)



Plug matrix  
See text.  
DSP S-Meter



Main Control Programmer (option)



PSU 12V

No  
1/ F  
to P  
2/ 7  
buil  
3/ 8  
4/ 1  
5/ 1  
ont  
6/ 1  
But  
7/ C  
ad